



U-Boot Reference Manual

© Digi International Inc. 2007. All Rights Reserved.

The Digi logo is a registered trademark of Digi International, Inc.

All other trademarks mentioned in this document are the property of their respective owners.

Information in this document is subject to change without notice and does not represent a commitment on the part of Digi International.

Digi provides this document “as is,” without warranty of any kind, either expressed or implied, including, but not limited to, the implied warranties of fitness or merchantability for a particular purpose. Digi may make improvements and/or changes in this manual or in the product(s) and/or the program(s) described in this manual at any time.

This product could include technical inaccuracies or typographical errors. Changes are periodically made to the information herein; these changes may be incorporated in new editions of the publication.

Digi International Inc.

11001 Bren Road East

Minnetonka, MN 55343 (USA)

☎ +1 877 912-3444 or +1 952 912-3444

www.digiembedded.com

Contents

1	Conventions used in this manual	5
2	Acronyms and Abbreviations	6
3	Introduction	7
3.1	What is a boot loader?	7
3.2	What is U-Boot?	7
3.3	U-Boot Features	7
3.3.1	Customizable footprint	7
3.3.2	Monitor	7
3.3.3	Variables	8
3.3.4	Kernel images downloadable via Ethernet and USB	8
3.3.5	Numbers assumed in hexadecimal format	8
3.4	The boot process	8
4	U-Boot commands	9
4.1	Overview	9
4.2	Built-in commands	9
4.2.1	Information commands	11
4.2.2	Network commands	11
4.2.3	USB commands	12
4.2.4	Memory commands	12
4.2.5	Serial port commands	13
4.2.6	I2C commands	13
4.2.7	Environment variable commands	13
5	Environment variables	14
5.1	Overview	14
5.2	Simple and recursive variables	14
5.3	Scripts	15
5.4	System variables	16
5.4.1	Common system variables	16
5.4.2	Dynamic variables	17
5.4.3	Digi custom variables	17
5.4.4	Protected variables	17
6	Boot commands	18
6.1	Overview	18
6.2	Reading images into RAM	18
6.2.1	From Ethernet	18
6.2.2	From USB	18
6.2.3	From flash	19
6.3	Boot images in RAM	19
6.4	Direct booting	20
6.4.1	Direct booting with Microsoft Platform Builder / Visual Studio	21
6.5	Automatic booting	21
7	Using NVRAM	22
7.1	The intnvram command	22
7.1.1	Mappings of variables	24
7.2	The flpart command	24
7.2.1	A partition table entry	25
7.2.2	Changing the partition table	26

8	Firmware update commands	27
8.1	Overview.....	27
8.2	Updating flash with images in RAM	27
8.3	Direct updating	28
8.3.1	Update limits	28
9	U-Boot development	29
	Index	30

1 Conventions used in this manual

This list shows the typographical conventions used in this guide:

<i>Style</i>	In text, to introduce new terms
Style	In text, for command and variable names.
<code>style</code>	In examples, to show the text that should be typed literally by the user.
Style	In text and syntax discussions, to display command variables.
#	A prompt that indicates the action is performed in the target device.
\$	A prompt that indicates the action is performed in the host computer.
<field>	A mandatory field that must be replaced with a value.
[field]	An optional field.
[a b c]	A field that can take one of several values.

This manual also uses these frames and symbols:



This is a warning. It helps solve or to avoid common mistakes or problems



This is a hint. It contains useful information about a topic



\$ This is a host computer session
\$ **Bold text indicates what must be input**



This is a target session
Bold text indicates what must be input

2 Acronyms and Abbreviations

BIOS	Basic Input Output System
CPU	Central Processing Unit
FAT	File Allocation Table
I2C	Inter-Integrated Circuit
MBR	Master Boot Record
NVRAM	Non Volatile RAM
OS	Operating System
PC	Personal Computer
RAM	Random Access Memory
TFTP	Trivial File Transfer Protocol
USB	Universal Serial Bus

3 Introduction

3.1 What is a boot loader?

Microprocessors can execute only code that exists in memory (either ROM or RAM), while operating systems normally reside in large-capacity devices such as hard disks, CD-ROMs, USB disks, network servers, and other permanent storage media.

When the processor is powered on, the memory does not hold an operating system, so special software is needed to bring the OS into memory from the media on which it resides. This software is normally a small piece of code called the *boot loader*. On a desktop PC, the boot loader resides on the master boot record (MBR) of the hard drive and is executed after the PC's *basic input output system* (BIOS) performs system initialization tasks.

In an embedded system, the boot loader's role is more complicated because these systems rarely have a BIOS to perform initial system configuration. Although the low-level initialization of the microprocessor, memory controllers, and other board-specific hardware varies from board to board and CPU to CPU, it must be performed before an OS can execute.

At a minimum, a boot loader for an embedded system performs these functions:

- Initializing the hardware, especially the memory controller
- Providing boot parameters for the OS
- Starting the OS

Most boot loaders provide features that simplify developing and updating firmware; for example:

- Reading and writing arbitrary memory locations
- Uploading new binary images to the board's RAM from mass storage devices
- Copying binary images from RAM into flash

3.2 What is U-Boot?

U-Boot is an open-source, cross-platform boot loader that provides out-of-box support for hundreds of embedded boards and many CPUs, including PowerPC, ARM, XScale, MIPS, Coldfire, NIOS, Microblaze, and x86.

For more information about the U-Boot project see <http://sourceforge.net/projects/u-boot/> and <http://www.denx.de/wiki/DULG/Manual>.

3.3 U-Boot Features

3.3.1 Customizable footprint

U-Boot is highly customizable to provide both a rich feature set and a small binary footprint.

3.3.2 Monitor

U-Boot has a command shell (also called a monitor) for working with U-Boot commands to create a customized boot process.

3.3.3 Variables

U-Boot uses environment variables that can be read or written to and from non-volatile media. Use these variables to create scripts of commands (executed one after the other) and to configure the boot process.

3.3.4 Kernel images downloadable via Ethernet and USB

Because U-Boot can download a kernel image using either Ethernet or USB, no flash programming is needed to test a new kernel. This prevents the deterioration of flash caused by repeated flash erases and writes.

3.3.5 Numbers assumed in hexadecimal format

Numbers used by U-Boot are always considered to be in hexadecimal format. For example, U-Boot understands number 30100000 as 0x30100000.

3.4 The boot process

After power-up or reset, the processor loads the U-Boot boot loader in several steps.

- The processor does these steps:
 - Executes a primary bootstrap that configures the interrupt and exception vectors, clocks, and SDRAM
 - Decompresses the U-Boot code from flash to RAM
 - Passes execution control to the U-Boot
- U-Boot does these steps:
 - Configures the Ethernet MAC address, flash, and, serial console
 - Loads the settings stored as environment variables in non-volatile memory
 - After a few seconds (a programmable length of time), automatically boots the pre-installed kernel

To stop the automatic booting (*autoboot*) of the pre-installed kernel, send a character to the serial port by pressing a key from the serial console connected to the target. If U-Boot is stopped, it displays a command line console (also called *monitor*).

	<pre>U-Boot 1.1.4 (Apr 20 2007 - 21:47:39) DUB-RevA for Digi ConnectCore Wi-9C on Development Board DRAM: 64 MB NAND: 128 MiB In: serial Out: serial Err: serial CPU: NS9360 @ 154.828800MHz Strap: 0x03 SPI ID:2007/02/21, V1_4, CC9C/CCW9C, SDRAM 64MByte, CL2, 7.8us, LE FPGA: wifi.ncd, 2007/01/25, 17:49:41, V2.01 Hit any key to stop autoboot: 0</pre>
---	--

4 U-Boot commands

4.1 Overview

U-Boot has a set of built-in commands for booting the system, managing memory, and updating an embedded system's firmware. Custom built-in commands can be created by modifying U-Boot source code.

4.2 Built-in commands

For a complete list and brief descriptions of the built-in commands, at the U-Boot monitor prompt, enter either of these commands:

- **help**
- **?**

A list of commands and help text like this is displayed:



```
# help
? - alias for 'help'
autoscr - run script from memory
base - print or set address offset
bdfinfo - print Board Info structure
boot - boot default, i.e., run 'bootcmd'
bootd - boot default, i.e., run 'bootcmd'
bootelf - Boot from an ELF image in memory
bootm - boot application image from memory
bootp - boot image via network using BootP/TFTP protocol
bootvx - Boot vxWorks from an ELF image
cmp - memory compare
coninfo - print console devices and information
cp - memory copy
crc32 - checksum calculation
date - get/set/reset date & time
dboot - Digi ConnectCore modules boot commands
dcache - enable or disable data cache
dhcp - invoke DHCP client to obtain IP/boot params
echo - echo args to console
envreset - Sets environment variables to default setting
fatinfo - print information about filesystem
fatload - load binary file from a dos filesystem
fatls - list files in a directory (default /)
flpart - displays or modifies the partition table.
go - start application at address 'addr'
help - print online help
icache - enable or disable instruction cache
icrc32 - checksum calculation
iloop - infinite loop on address range
imd - i2c memory display
iminfo - print header information for application image
imm - i2c memory modify (auto-incrementing)
imw - memory write (fill)
inm - memory modify (constant address)
intnvr - displays or modifies NVRAM contents like IP or partition table
iprobe - probe to discover valid I2C chip addresses
itest - return true/false on integer compare
loadb - load binary file over serial line (kermit mode)
loads - load S-Record file over serial line
loady - load binary file over serial line (ymodem mode)
loop - infinite loop on address range
md - memory display
mm - memory modify (auto-incrementing)
```

```

mtest - simple RAM test
mw - memory write (fill)
nand - NAND sub-system
nboot - boot from NAND device
nfs - boot image via network using NFS protocol
nm - memory modify (constant address)
ping - send ICMP ECHO_REQUEST to network host
printenv- print environment variables
printenv_dynamic- Prints all dynamic variables
rarpboot- boot image via network using RARP/TFTP protocol
reset - Perform RESET of the CPU
run - run commands in an environment variable
saveenv - save environment variables to persistent storage
setenv - set environment variables
sleep - delay execution for some time
sntp - synchronize RTC via network
tftpboot- boot image via network using TFTP protocol
update - Digi ConnectCore modules update commands
usb - USB sub-system
usbboot - boot from USB device
version - print monitor version

```

The available commands vary according to the capabilities of the hardware platform.

For more information about a command, enter:

help *command name*

For example:



```

# help run
run var [...]
- run the commands in the environment variable(s) 'var'

```



*As the first characters of a command are entered, U-Boot searches its list of built-in commands until it finds a match. For example, entering **save** or **sav** or even **sa**, causes U-Boot to execute the **saveenv** command.*

*U-Boot needs enough characters to be entered to determine the command to execute. For example, if **loa** is entered, U-Boot cannot tell whether to execute **loadb**, **loads** or **loady**, and an **Unknown command** message is displayed.*

4.2.1 Information commands

Commands that information about the development board, devices, memory, etc., include:

Command	Description
<code>bdinfo</code>	Prints board info structure.
<code>coninfo</code>	Prints console devices and information.
<code>date [MMDDhhmm][CC]YY[.ss]</code>	Gets, sets, or resets system date/time.
<code>fatinfo <interface> <dev[:part]></code>	Prints information about the file system from <i>dev</i> on <i>interface</i> .
<code>iminfo addr [addr ...]</code>	Prints header information for the application image starting at the <i>addr</i> address in memory, including verification of the image contents (magic number, header, and payload checksums). Works only for Linux kernel images.
<code>nand bad</code>	Shows NAND bad blocks.
<code>nand info</code>	Shows available NAND devices.
<code>version</code>	Displays U-Boot version and timestamp.

4.2.2 Network commands

Network-related commands include:

Command	Description
<code>bootp [loadAddress] [bootFilename]</code>	Boots the image over the network using the BootP/TFTP protocol. If no argument is given, bootp takes the values from the <i>loadaddr</i> and <i>bootfile</i> environment variables.
<code>dhcp</code>	Requests an IP address from a DHCP server, set in the <i>serverip</i> system variable. If the <i>autoload</i> variable is set to <i>yes</i> , also transfers the file to which the <i>bootfile</i> environment variable points to the <i>loadAddress</i> RAM memory address by TFTP.
<code>nfs [loadAddress] [host ip addr:bootfilename]</code>	Using NFS, transfers image <i>bootfilename</i> into the RAM address <i>loadAddress</i> .
<code>ping <pingAddress></code>	Pings the IP address passed as parameter. If the other end responds, this message is displayed: host <pingAddress> is alive.
<code>rarpboot [loadAddress] [bootfilename]</code>	Using RARP/TFTP, transfers image into the RAM address <i>loadAddress</i> .
<code>sntp</code>	Gets the date and time from the NTP server to which the <i>ntpserverip</i> environment variable points..
<code>tftpboot [loadAddress] [bootfilename]</code>	Using FTP, transfers image <i>bootfilename</i> into the RAM address <i>loadAddress</i> .



If the *autostart* variable is set to 'yes', all commands (except *ping*) boot the transferred image by calling the *bootm* command. *bootm* does not work for WinCE images. If working with a WinCE image file, either set the *autostart* variable to 'no' or delete it before executing these network commands.

4.2.3 USB commands

To access the USB subsystem, use the **usb** command, followed by its operations:

Command	Description
usb reset	Resets (rescans) USB controller.
usb stop [<i>f</i>]	Stops USB [<i>f</i>]=force stop.
usb tree	Shows USB device tree.
usb info [<i>dev</i>]	Shows available USB devices.
usb storage	Shows details of USB storage devices.
usb dev [<i>dev</i>]	Shows or sets current USB storage device.
usb part [<i>dev</i>]	Prints the partition table of one (<i>dev</i>) or all USB storage devices.
usb read <i>addr blk# cnt</i>	Reads <i>cnt</i> blocks starting at block <i>blk#</i> to RAM address <i>addr</i> .
fatload usb < <i>dev[:part]</i> > < <i>addr</i> > < <i>filename</i> >	Reads <i>filename</i> image from partition <i>part</i> of USB device <i>dev</i> into the RAM memory address <i>addr</i> . If <i>part</i> is not specified, partition 1 is assumed.
usbboot	Boots from USB device.

4.2.4 Memory commands

These commands manage RAM memory:

Command	Description
cmp[.b, .w, .l] <i>addr1 addr2 count</i>	Compares memory contents from address <i>addr1</i> to <i>addr2</i> for as many <i>count</i> bytes, words, or long words.
cp[.b, .w, .l] <i>source target count</i>	Copies memory contents from address <i>source</i> to <i>target</i> for as many <i>count</i> bytes, words, or long words.
go <i>addr [arg ...]</i>	Starts the application at address <i>addr</i> passing <i>arg</i> as arguments.
md[.b, .w, .l] <i>address [# of objects]</i>	Displays memory contents at address <i>address</i> for as many <i>[# of objects]</i> bytes, words, or long words.
mm[.b, .w, .l] <i>address</i>	Modifies locations of memory, beginning at <i>address</i> , which gets auto-incremented.
mw[.b, .w, .l] <i>address value [count]</i>	Writes <i>value</i> into <i>address</i> for as many <i>count</i> bytes, words, or long words.
nm[.b, .w, .l] <i>address</i>	Modifies a fixed location of memory.
nand read <i>addr off size</i>	Copies memory contents from flash address <i>off</i> to RAM address <i>addr</i> for as many <i>size</i> bytes (only for NAND flash memories).
nand write <i>addr off size</i>	Copies memory contents from RAM address <i>addr</i> to flash address <i>off</i> for as many <i>size</i> bytes (NAND flash memories only).
nand erase [<i>off size</i>]	Erases <i>size</i> bytes from address <i>off</i> . Erases entire device if no parameters are specified (NAND flash memories only). U-Boot skips bad blocks and shows their addresses.
nand dump[.oob] <i>off</i>	Dumps NAND page at address <i>off</i> with optional out-of-band data (only for NAND flash memories).

nboot *address dev [off]*

Boots image from NAND device *dev* at offset *off* (transferring it first to RAM *address*).

4.2.5 Serial port commands

Use these commands to work with the serial line:

Command	Description
loadb [<i>off</i>] [<i>baud</i>]	Loads binary file over serial line with offset <i>off</i> and baud rate <i>baud</i> (Kermit mode).
loads [<i>off</i>]	Loads S-Record file over the serial line with offset <i>off</i> .
loady [<i>off</i>] [<i>baud</i>]	Loads binary file over the serial line with offset <i>off</i> and baud rate <i>baud</i> (Ymodem mode).

4.2.6 I2C commands

These commands interface with the I2C interface:

Command	Description
iloop chip <i>address</i> [.0, .1, .2] [<i># of objects</i>]	Loops, reading a set of I2C addresses.
imd chip <i>address</i> [.0, .1, .2] [<i># of objects</i>]	Displays I2C memory.
imm chip <i>address</i> [.0, .1, .2]	Modifies I2C memory with an auto-incremented address.
imw <i>address</i> [.0, .1, .2] <i>value</i> [<i>count</i>]	Fills an I2C memory range with <i>value</i> .
inm chip <i>address</i> [.0, .1, .2]	Modifies memory, reads and keeps an address.
iprobe	Discovers valid I2C chip addresses.
itest [.b, .w, .l, .s] [*] <i>value1</i> < <i>op</i> > [*] <i>value2</i>	Returns TRUE/FALSE on integer compare.

4.2.7 Environment variable commands

To read, write, and save environment variables, use these commands:

Command	Description
printenv [<i>name</i> ...]	If no variable is given as argument, prints all U-Boot environment variables. If a list of variable names is passed, prints only those variables.
printenv_dynamic	Prints all dynamic variables.
envreset	Overwrites all current variables values to factory default values. Does not reset the <i>wlanaddr</i> or <i>ethaddr</i> variables or any other persistent settings stored in NVRAM (see topic 7.1).
saveenv	Writes the current variable values to non-volatile memory (NVRAM).
setenv <i>name</i> [<i>value</i>]	If no value is given, the variable is deleted. If the variable is dynamic, it is reset to the default value. If a value is given, sets variable <i>name</i> to value <i>value</i> .

5 Environment variables

5.1 Overview

U-Boot uses environment variables to tailor its operation. The environment variables configure settings such as the baud rate of the serial connection, the seconds to wait before auto boot, the default boot command, and so on.

These variables must be stored in either non-volatile memory (NVRAM) such as an EEPROM or a protected flash partition.

The factory default variables and their values also are stored in the U-Boot binary image itself. This allows recovering the variables and their values at any time with the **envreset** command.

Environment variables are stored as strings (case sensitive). Custom variables can be created as long as there is enough space in the NVRAM.

5.2 Simple and recursive variables

Simple variables have a name and a value (given as a string):



```
# setenv myNumber 123456
# printenv myNumber
myNumber=123456
```

To expand simple variables, enclose them in braces and prefix a dollar sign:



```
# setenv myNumber 123456
# setenv var This is my number: ${myNumber}
# printenv var
var=This is my number: 123456
```

Recursive variables (or scripts) contain one or more variables within their own value. The inner variables are not expanded in the new variable. Instead, they are expanded when the recursive variable is run as a command, as shown here:



```
# setenv dumpaddr md.b \${addr} \${bytes}
# printenv dumpaddr
dumpaddr=md.b ${addr} ${bytes}
# setenv addr 2C000
# setenv bytes 5
# run dumpaddr
0002c000: 00 00 00 00 00 .....

```

To prevent variables from being expanded into other variables' values, use the back slash **** before **\$**.

5.3 Scripts

In U-Boot, a script is made up of variables that contain a set of commands that are executed one after another.

Consider this variable:



```
# printenv cmd1
setenv var val;printenv var;saveenv
```

Running this script with **run cmd1** creates the **var** variable with value **val**, prints the value **val** to the console, and saves the variables to either the EEPROM or flash partition dedicated to variables.



```
# run cmd1
var=val
Saving Environment to Flash...
Un-Protected 1 sectors
Erasing Flash...
. done
Erased 1 sectors
Writing to Flash... done
Protected 1 sectors
```

Separate the commands in a script with semicolons (;). As with recursive variables, semicolons must be preceded by a back-slash sign to prevent them from being interpreted as the termination of the first command itself.

To save **cmd1**, enter:



```
# setenv cmd1 setenv var val\;printenv var\;saveenv
```

For running commands stored in variables, use the **run** command and its variables separated by spaces:



```
# setenv cmd1 setenv var val
# setenv cmd2 printenv var
# setenv cmd3 saveenv
# run cmd1 cmd2 cmd3
```

5.4 System variables

U-Boot uses several built-in system variables:

5.4.1 Common system variables

Variable	Description
<code>autoload</code>	If set to no (or any string beginning with n), the rarpboot , bootp , or dhcp command performs a configuration lookup from the BOOTP / DHCP server but does not try to load any image using TFTP.
<code>autostart</code>	If set to yes , an image loaded using the rarpboot , bootp , dhcp or tftpboot commands is automatically started (by internally calling the bootm command).
<code>baudrate</code>	The baud rate of the serial connection.
<code>bootcmd</code>	Defines a command string that is automatically executed when the initial countdown is not interrupted. Executed only when the bootdelay variable is also defined.
<code>bootdelay</code>	Seconds to wait before running the automatic boot process in bootcmd .
<code>bootfile</code>	Name of the default image to load with TFTP.
<code>dhcp</code>	If set to on , enables the DHCP client to obtain a dynamic IP for the Ethernet interface.
<code>dhcp_wlan</code>	For modules with a WLAN interface, if set to on , enables the DHCP client to obtain a dynamic IP for the WLAN interface.
<code>dnsip</code>	IP address of the primary DNS server,
<code>dnsip2</code>	IP address of the secondary DNS server.
<code>fileaddr</code>	The RAM address where the last file transferred by TFTP was placed.
<code>filesize</code>	The size of the last file transferred by TFTP or USB.
<code>gatewayip</code>	IP address used as network gateway.
<code>ipaddr</code>	IP address of the target's Ethernet interface.
<code>ipaddr_wlan</code>	IP address of the target's WLAN interface (for modules that have it).
<code>netmask</code>	Subnet mask of Ethernet interface.
<code>netmask_wlan</code>	Subnet mask of WLAN interface (for modules that have it).
<code>ntpserverip</code>	NTP server IP address (for getting the date/time).
<code>stdin</code>	Standard input system.
<code>stdout</code>	Standard output system.
<code>stderr</code>	Standard error output system.
<code>serverip</code>	IP address of the host PC (for remote connections like TFTP transfers).
<code>verify</code>	If set to n or no , disables the checksum calculation over the complete image in the bootm command to trade speed for safety in the boot process. Note that the header checksum is still verified.

5.4.2 Dynamic variables

Depending on the module, the partitioning information, and so on, U-Boot generates some variables "on the fly" if they do not already exist in U-Boot.

These variables can be overwritten with **setenv** thus becoming standard U-Boot variables. Dynamic variables which are not set with **setenv** also exist (they are automatically created), but they cannot be printed with **printenv**.

Some of these variables are OS-specific for different OS implementations (Linux, Windows CE, NET+OS). They provide special functionality for the OS running in the platform.



For more information, see the boot loader development chapter of the development kit's documentation.

5.4.3 Digi custom variables

The development board in the kit may have two user buttons. If it does, U-Boot can detect which one is pressed when it starts.

Pressing either key when the boot loader is starting, executes the **key1** or **key2** variable before the **bootcmd**. This allows for different boot scripts, depending on the key pressed during boot, for booting two different kernels, such as a dual Linux/Windows CE or two versions of the same OS.

If the **key1** and **key2** variables do not exist, the normal **bootcmd** is executed.

When the two keys are pressed during boot, both are detected as pressed, and both scripts are launched. The script in variable **key1** is always executed before the one in variable **key2**.



Detection of user keys can be disabled for customized hardware where these keys do not exist. This requires reconfiguring and recompiling U-Boot. See chapter 9 for information about U-Boot development.

5.4.4 Protected variables

Several variables are of great relevance for the system and are stored in a protected section of NVRAM.

Some of these protected variables are, for example, the serial number of the module and the MAC addresses of the network interfaces, which are programmed during production and normally should not be changed.

6 Boot commands

6.1 Overview

U-Boot runs code placed in RAM, although it also can read from other media. The boot process normally takes place in two steps:

- Reading the OS image from media (Ethernet, flash, USB) into RAM
- Jumping to the first instruction of the image in RAM

6.2 Reading images into RAM

6.2.1 From Ethernet

The most common way to boot an image during development is by transferring it using TFTP over the Ethernet interface. To do this, use the **tftpboot** command, passing:

- The address of RAM in which to place the image (**loadAddress**)
- The image file name (**bootfilename**)



```
# tftpboot <loadAddress> <bootfilename>
```

The TFTP transfer occurs between the **serverip** address (host) and the **ipaddr** address (target). The host must be running a TFTP server and have **bootfilename** archive placed in the TFTP-exposed directory.

For Linux kernel images, if the **autostart** variable is set to **yes**, this command directly boots the kernel after downloading it.

6.2.2 From USB

Another way to boot an image is by reading it from a USB flash storage device. The USB disk must be formatted in FAT file system.

To read an image from a USB flash disk, enter:



```
# usb reset  
# fatload usb <dev>[:partition] <loadAddress> <bootfilename>
```

This command reads file **bootfilename** from device **dev**, partition **partition** of the USB flash disk into the RAM address **loadAddress**. **Device** and **partition** are given as a number (0, 1, 2...).

If no partition is specified, partition 1 is assumed.

6.2.3 From flash

For standalone booting, the device can read the image from flash, avoiding dependency on any external hardware.

In targets with NOR flash memories, do this with memory commands:



```
# cp.[b/w/l] <sourceAddress> <loadAddress> <count>
```

This command copies **count** bytes, words, or long words (depending on the suffix used -: b, w, l - from **sourceAddress** into **loadAddress**.

In targets with NAND flash memories, the special NAND commands must be used:



```
# nand read <loadAddress> <sourceAddress> <count>
```

This command copies **count** bytes from **sourceAddress** into **loadAddress**.

6.3 Booting images in RAM

After the image is transferred to RAM, it can be booted in either of two ways, depending on the OS:

- For Windows CE images:



```
# go <loadAddress>
```

- For Linux images:



```
# bootm <loadAddress>
```

where **loadAddress** (in both cases) is the address in RAM at which the image resides.



Windows CE images must be compiled with the information about the address in RAM from which they will be booted. For example, if a WinCE kernel is compiled with a boot address of 0x2C0000, it can be transferred to a different address, but the system can boot only from the compiled-in address.

6.4 Direct booting

To simplify the boot process, Digi's U-Boot version includes the **dboot** built-in command, which reads the OS image from the media and runs it from RAM in a single step.

The syntax for the **dboot** command is:



```
# dboot <os> <media>
```

where

- **os** is **linux**, **wce**, **eboot**, **netos** or any partition name.
- **media** is **flash**, **tftp** or **usb**.



If the **dhcp** variable is set to **yes** or **on**, the command first gets an IP address from the DHCP server to which the **serverip** variable points.

For example, to boot linux from flash, execute:



```
# dboot linux flash
```

To boot a partition from flash, a valid partition name must be provided. To print the partitions table, use the **flpart** command (for more information about this command see topic 7.2). Then execute the command with the selected partition name:



```
# flpart
Nr | Name          | Start      | Size      | Type          | FS      | Flags
-----|-----|-----|-----|-----|-----|-----
0 | U-Boot        | 0          | 768 KiB   | U-Boot        | None    | fixed
1 | NVRAM         | 768 KiB   | 512 KiB   | NVRAM         | None    | fixed
2 | Kernel        | 1280 KiB  | 3 MiB     | Linux-Kernel  | None    |
3 | RootFS-JFFS2 | 4352 KiB  | 16 MiB    | Filesystem    | JFFS2   | rootfs
4 | User-JFFS2    | 20736 KiB | 12 MiB    | Filesystem    | JFFS2   |
5 | Kernel-2      | 33024 KiB | 2 MiB     | Linux-Kernel  | None    |
# dboot Kernel-2 flash
```



Partition names are case sensitive, so **kernel-2** is a partition name different from **Kernel-2**.

6.4.1 Direct booting with Microsoft Platform Builder / Visual Studio

The **eboot** program is used to interconnect the target to the Windows CE development system (Platform Builder or Visual Studio). **Eboot** sends **BOOTME** messages to the development system program. These two programs talk to each other to transfer and debug the Windows CE kernel.

This is the command for booting with Platform Builder / Visual Studio:



```
# dboot eboot
```

This command reads the **eboot** image from flash into a specific RAM address and jumps to this image for execution.

6.5 Automatic booting

If U-Boot is not interrupted after the delay established in **bootdelay**, the automatic boot process takes place. Automatic booting consists of running what is specified in the **bootcmd** environment variable.

In other words, automatic booting has the same effect as doing either of the next two examples:



```
# run bootcmd
```



```
# boot
```

If, for example, to automatically boot a WinCE image from TFTP server, set **bootcmd** like this:



```
# setenv bootcmd dboot wce tftp
```

Or, to automatically boot a Linux image from flash, set **bootcmd** like this:



```
# setenv bootcmd dboot linux flash
```



If *bootdelay* is set to 0, the autoboot happens immediately after U-Boot starts. To stop the process and enter the monitor, press a key as soon as the first U-Boot output lines appear.

7 Using NVRAM

An embedded OS requires some persistent settings; for example, MAC address, IP address, Internet gateway, flash partition table, and U-Boot environment variables. Some of these are changed only in production and others only during custom setup.

These settings must be stored in non-volatile memory (NVRAM) so they are not lost when the target is powered off.

- For modules that have an I2C EEPROM (such as the ConnectCore 9P family), NVRAM is the EEPROM memory.
- For modules that do not have I2C EEPROM, a flash partition is reserved for this purpose.

The contents are protected by a CRC32 checksum. They also are mirrored to either a different I2C location or a second flash partition. In this way, if anything goes wrong or data becomes corrupted, the good image is taken and the bad one is automatically repaired when booting U-Boot or running the **intnvram** command.

7.1 The **intnvram** command

Protected variables stored in NVRAM can be read, modified, erased or stored with the **intnvram** command.

Changes made to NVRAM with the **intnvram** command are kept in RAM. U-Boot writes the changes to NVRAM only when the **saveenv** command or **intnvram save** command is executed.



Executing an *envreset* resets U-Boot environment variables and saves them to NVRAM.

The syntax of the **intnvram** command is:



```
Usage: intnvram help|print <params>|printall|repair|reset|save|set <params>
```

```
help      : prints this
print     : prints selected parameters.
           E.g.: print module mac serialnr
printall  : prints complete contents and metainfo
repair    : Repairs the contents. If one image is
           bad, the good one is copied onto it.
           If both are good or bad, nothing happens.
reset     : resets everything to factory default values.
save      : saves the parameters
set       : sets parameters.
```

For help with this command, enter **intnvram help**.

To print the complete contents of the NVRAM settings, enter **intnvram printall**.

Either one parameter or a set of parameters can be set or printed. Parameters are grouped in blocks. This is the complete parameters list with the possible values some of them can take:



```

params for "set" or "print" can be
  module      [producttype=] [serialnr=] [revision=] [patchlevel=]
               [ethaddr1=] [ethaddr2=]
  network     [gateway=] [dns1=] [dns2=] [server=] [netconsole=] [ip1=]
               [netmask1=] [dhcp1=] [ip2=] [netmask2=] [dhcp2=]
  partition   [add] [del] [select=] [name=] [chip=] [start=] [size=]
               [type=] [flag_fixed=] [flag_readonly=]
               [flag_fs_mount_readonly=] [flag_fs_root=] [flag_fs_type=]
               [flag_fs_version=]
  os          [add] [del] [select=] [type=] [start=] [size=]

Params trailed with '=' require a value in the set command. In the print
command, '=' mustn't be used.

Possible Values are
  os type:      None,Critical,OS-Meta,U-Boot,Linux,EBoot,WinCE,Net+OS,
               Unknown,Application
  partition type: U-Boot,NVRAM,FPGA,Linux-Kernel,WinCE-EBoot,WinCE-Kernel,
               Net+OS-Kernel,Filesystem,WinCE-Registry,Unknown,
               Splash-Screen
  flag_fs_type: None,JFFS2,CRAMFS,INITRD,FlashFX,Unknown,YAFFS

Examples:
  intnvram print module ethaddr1 serialnr : prints mac address and
                                           serial number
  intnvram print partition select=0 name select=1 name : prints first and
                                                         second partition
                                                         name
  intnvram set network ip1=192.168.42.30 : changes the IP address
  
```

Specify the group of the parameter before the parameter itself. For example, to print the module's MAC address, execute:



```

# intnvram print module ethaddr1
ethaddr1=00:40:9D:2E:92:D4
  
```

For printing different parameters of a block, the block must be used only once. For example, to print the module IP and subnet mask of Ethernet interface, execute:



```

# intnvram print network ip1 ethaddr1
ip1=192.168.42.30
ethaddr1=00:40:9D:2E:92:D4
  
```

To set a parameter a valid value must be provided, as shown here:



```

# intnvram set network ip1=192.168.42.80
  
```

To access a partition parameter, address the specific partition with the parameter **select=*n***, where ***n*** is the index to the partition. This example prints the names of partitions 1 and 2:



```

# intnvram print partition select=0 name select=1 name
name=U-Boot
name=NVRAM
  
```

7.1.1 Mappings of variables

Some of the protected variables in NVRAM are mapped to U-Boot environment variables. Therefore, modifying them with **intnvr** command is the same as doing so with **setenv** command. For security reasons, however, some variables cannot be modified with the **setenv** command.

This table lists the mapped variables:

U-Boot variable	NVRAM parameter	Blocked for 'setenv'
ethaddr	ethaddr1	X
wlanaddr	ethaddr2	X
netmask	netmask1	
netmask_wlan	netmask2	
ipaddr	ip1	
ipaddr_wlan	ip2	
dnsip	dns1	
dnsip2	dns2	
dhcp	dhcp1	
dhcp_wlan	dhcp2	
serverip	server	
gatewayip	gateway	

7.2 The flpart command

To print, modify, or restore the partitions table, use the **flpart** command. This U-Boot command requires no arguments; the partitions table is created using a menu of options.

7.2.1 A partition table entry

A partition table entry contains these fields:

Field	Description
Number	Index of partition in the table
Name	Name of the partition
Chip	Index of flash chip (normally, only one)
Start	Physical start address of the partition (in hex)
Size	Size of the partition (in hex)
Type	Partition type (what it will contain) <ul style="list-style-type: none">• U-Boot• NVRAM• FPGA• Linux-Kernel• WinCE-EBoot• WinCE-Kernel• Net+OS-Kernel• Filesystem• WinCE-Registry• Unknown
FS	File system that the partition contains: <ul style="list-style-type: none">• None• JFFS2• CRAMFS• INITRD• FlashFX• YAFFS• Unknown
Flags	Flags (non-exclusive): <ul style="list-style-type: none">• read-only• mount read-only• rootfs

7.2.2 Changing the partition table

To modify the partition table, use the **flpart** command in U-Boot:



#	flpart					
Nr	Name	Start	Size	Type	FS	Flags
0	U-Boot	0	768 KiB	U-Boot	None	fixed
1	NVRAM	768 KiB	512 KiB	NVRAM	None	fixed
2	FPGA	1280 KiB	1 MiB	FPGA	None	fixed
3	EBoot	2304 KiB	1 MiB	WinCE-EBoot	None	
4	Registry	3328 KiB	1 MiB	WinCE-Registry	None	
5	Kernel	4352 KiB	20 MiB	WinCE-Kernel	None	

Commands:
a) Append partition
d) Delete partition
m) Modify partition
p) Print partition table
r) Reset partition table
q) Quit
Cmd (? for help)>

Partitions are added, modified, or deleted step-by-step; the command prompts for the necessary information.



*Start and Size values can be given as hexadecimal numbers (prefixed with **0x**) or as decimal numbers followed with **k** (for KiB) or **m** (for MiB).*

The partition table also can be reset to the default values. In this case, because the partition table differs according to the target's OS, the desired OS can be selected.



Changes take effect only after quitting 'flpart' and saving the changes.

When the size or start address of a partition has been changed, it is always necessary to erase it and write a new image to it.

8 Firmware update commands

8.1 Overview

The boot loader, kernel, and other data stored in flash form the firmware of the device. Because U-Boot can write any part of flash, its flash commands can be used to reprogram (update) any part of the firmware. This includes the boot loader itself.

The update process normally takes place in three steps:

- Reading image from media (Ethernet, USB) into RAM memory
- Erasing the flash that is to be updated
- Copying the image from RAM into flash

8.2 Updating flash with images in RAM

Flash memory must be updated with images located in RAM memory. Images are moved to RAM using either Ethernet or USB (see section 6.2 for more information).

To erase flash and copy the images from RAM to flash, use these commands:

- For NOR flash memory:



```
# erase address +size  
# cp.[b|w|l] sourceAddress targetAddress count
```

The first command erases **size** bytes beginning at **address**. The second command copies **count** bytes, words or long words (depending on the suffix used: b, w, l) from **sourceAddress** into **targetAddress**.

- For NAND flash memory:



```
# nand erase address size  
# nand write sourceAddress targetAddress count
```

The first command erases **size** bytes beginning at **address**. The second command copies **count** bytes from **sourceAddress** into **targetAddress**.



The erasure of the flash comprises whole erase-blocks. The *address* and *size* parameters must be multiples of the erase-blocks of the flash memory. See the module's flash datasheet for the erase-block size.

8.3 Direct updating

Digi's U-Boot version includes the built-in **update** command. This command copies the image from the media to RAM, erases the flash size needed for the image, and moves the image from RAM into flash in a single step, simplifying the update process.

Here is the syntax for **update**:



```
# help update
update partition source [file]
- updates 'partition' via 'source'
  values for 'partition': uboot, linux, rootfs, userfs, eboot, wce
                        or any partition name
  values for 'source': tftp, usb
  values for 'file': the file to be used for updating
```



*If the **dhcp** variable is set to **yes** or **on**, the command first gets an IP address from the DHCP server pointed to by the **serverip** variable.*

8.3.1 Update limits

The **update** command in U-Boot transfers files to RAM, erases the flash partition, and writes the files from RAM into flash memory.

The file that is transferred is copied to a specific physical address in RAM; therefore, the maximum length of the file to update is:

$$\text{Update file size limit} = \text{Total RAM memory} - \text{RAM offset where the file was loaded}$$

As a general rule, U-Boot does not allow updating a flash partition with a file size that exceeds the available RAM memory. This means that, for example, if a module has 32MB RAM and 64MB flash and the file for updating a partition is 35MB, U-Boot will not do it.

This limitation is due to the RAM memory size, as U-Boot first needs to transfer the file to RAM before copying it to flash.



For updating partitions with files larger than the available RAM memory, see your OS-specific update flash tool.

9 U-Boot development

U-Boot is an open source project. Sources are freely distributed, and can be modified to meet requirements for a boot loader.

The project sources are ready to be installed and compiled in a Linux environment. If a Linux machine is not available for development, install the *Cygwin X-Tools* software (<http://www.cygwin.com>). The *X-Tools* provide a Unix-like development environment for Windows, based on *Cygwin* and the GNU toolchain, to cross-compile the boot loader.

For information about installing the U-Boot sources, modifying platform-specific sources, and recompiling the boot loader, see your development kit documentation. Procedures may vary according to hardware platform and OS.

Index

A	
autoload system variable	16
automatic booting	21
autostart system variable	16
available commands	
and hardware platform	10
available RAM	
and update limits	28
B	
baudrate system variable	16
bdinfo command	11
BIOS	6, 7
<i>boot loader</i>	
defined	7
boot process	8
bootcmd system variable	16
bootdelay system variable	16
booting images in RAM	19
bootm command	
and Windows CE images	11
bootp command	11
built-in commands	
creating	9
C	
cmp command	12
commands	
boot	18
built-in	9
environment variables	13
firmware update	27
flpart	24
information	11
intnvram	22
memory	12
network	11
serial port	13
type-ahead	10
update	28
USB	12
coninfo command	11
conventions in this manual	5
cp command	12
creating built-in commands	9
custom variables	17
D	
date command	11
dhcp command	11
dhcp system variable	16
dhcp wlan system variable	16
Digi custom variables	17
direct booting	20
dnsip system variable	16
dnsip2 system variable	16
dynamic variables	17
E	
environment variable commands	13
environment variables	
simple and recursive	14
envreset command	13
F	
FAT	6
fatinfo command	11
fileaddr system variable	16
filesize system variable	16
firmware	
update commands	27
flash	
updating with images in RAM	27
flpart command	24
G	
gatewayip system variable	16
go command	12
H	
hardware platform	
and available commands	10

I	
I2C	6
I2C commands	13
iloop command	13
imd command	13
iminfo command	11
imm command	13
imw command	13
information commands	11
inm command	13
intnvrn	22
ipaddr system variable.....	16
ipaddr wlan system variable	16
iprobe command	13
itest command	13
L	
loadb command	13
loads command	13
loady command	13
M	
MBR.....	6
md command.....	12
memory	
comparing.....	12
copying	12
copying contents from flash to RAM address.....	12
copying contents from RAM to flash address.....	12
displaying contents.....	12
dumping NAND page.....	12
erasing.....	12
modifying a fixed location	12
modifying contents.....	12
writing values to.....	12
memory commands	12
mm command.....	12
mw command	12
N	
nand bad command.....	11
nand dump command.....	12
nand erase command.....	12
nand info command	11
nand read command.....	12
nand write command	12
nboot command	12, 13
nboot memory	
booting image from NAND device	13
netmask system variable	16
netmask wlan system variable.....	16
network commands.....	11
nfs command	11
nm command	12
non-volatile memory (NVRAM)	
and persistent settings.....	22
ntpserverip system variable	16
NVRAM.....	6
P	
partition table	
entries, contents of	25
modifying	26
resetting	26
persistent settings.....	22
ping command	11
printenv command	13
protected variables	17
R	
rarpboot command.....	11
reading images into RAM	18
recursive variables.....	14
S	
saveenv command.....	13
scripts.....	15
serial port commands	13
serverip system variable	16
setenv command	13
simple variables	14
sntp command	11
stderr system variable.....	16
stdin system variable	16
stdout system variable	16
system variables	16

T

TFTP	6
tftpboot command	11

U

U-Boot	
boot process	8
built-in commands.....	9
command shell (monitor)	7
commands	9
described	7
development	29
hexadecimal assumed for numbers.....	8
source code, modifying.....	9
variables.....	8
update command	28
update limits	
and available RAM.....	28

updating flash.....	27
USB.....	6
USB commands	12

V

variables	
Digi custom	17
Digi-custom	17
dynamic.....	13, 17
environment	13, 14
in scripts	15
mapping of	24
protected	17
recursive.....	14
simple.....	14
system.....	16
verify system variable	16
version command.....	11